PRACTICAL GUIDE · ENGLISH

Enjoy more from your Xsarius box.

Clear steps for everyday use of a Xsarius Android media streamer with PremiumTV+.

No streaming services or support for them
ASAT.NL does not supply streaming services, channel packages or IPTV subscriptions, and does not provide support for them. Ask your provider about channels, playlists, login details or service outages. This guide provides general information about equipment and apps.

Which boxes does this guide cover?
This guide follows the buttons and menus in the supplied OTT Android manual. Your model's remote control and software may differ. Where needed, use the equivalent on-screen control.

Quick start

01 Switch on your television and Xsarius box. Select the TV's **HDMI input** connected to the box.

02 If the Android home screen appears, select **PremiumTV+** using the arrow buttons and press **OK**. Sometimes the last channel opens automatically.

03 Select an available channel and press **OK**. Your box needs an internet connection and a working content source.

02 · Controls	The main buttons at a glance.
03 · Live TV	Choose channels and manage favourites.
04 · Catch-up	Programme guide, catch-up and subtitles.
05 · Films & series	VOD, series, search and radio.
06 · Recording	Record now, schedule and play back.
07 · More help	USB, microSD, YouTube and troubleshooting.

This ASAT.NL guide is a revised English edition based on the supplied "Xsarius OTT Android Beknopte handleiding.pdf". It does not replace the manufacturer's manual for your particular model.

Know your remote control.

The names below refer to buttons in the original manual. Look for the same name or function on your remote. On-screen labels may vary with the selected language and software version.

Arrow buttons	Move up, down, left or right through lists and menus.
OK	Confirm your choice. While watching, this button often opens extra controls or a channel list.
Back	Go back one step. Useful for leaving a menu or list.
Home	Go to the box’s Android home screen.
Page + / -	In the original controls, these buttons move to the next or previous channel.
EPG	Open the electronic programme guide.
Heart	Add a channel to your favourites or remove it from them.
Blue button	Manage or move favourites in the relevant menu.
Yellow button	Open available options, including subtitles.
Live / VOD / Series / Radio	Go directly to live TV, films, series or radio, where available.
Play / Pause	Pause or resume, where the programme and provider support it.
REC / Stop	Start recording / stop playback or a recording.
Menu	Open additional options, such as your recordings list.

Lost your way?
Try **Back** first. To start again, press **Home** and reopen PremiumTV+.

ASAT.NL does not supply streaming services or provide support for them.

Find your channels quickly.

Channel groups appear beside the channel list. Your own favourites groups make channels easier to find.

Choose a different channel

01 **Within the same group:** while watching, press **Left** once. Use Up/Down to select a channel and press **OK**. You can also use Page + / - or enter the channel number.

02 **Switch to another group:** while watching, press **Left** twice. Choose a group, press **Right**, select a channel and confirm with **OK**.

Add a favourite

01 Open the channel you want and press **OK** again. Then press the **heart** button.

02 Choose an existing favourites folder, such as **Server Fav**, and confirm with **OK**.

03 Want your own folder? Choose **New group**, enter a name using the on-screen keyboard and confirm with **Done** and **OK**.

Put favourites in order

01 Open a channel in the favourites folder you want to organise. Press **OK**, then the **blue button**.

02 Select the channel to move and press the **blue button** again. Move the channel with the arrow buttons and confirm with **OK**.

03 Repeat for other channels. Press **Back** when finished.

Remove a favourite
Select the channel in your favourites, press **OK**, then the **heart** button. The star disappears. Press Back to finish.

ASAT.NL does not supply streaming services or provide support for them.

Watch when it suits you.

Catch-up, pausing and subtitles are available only when your source, channel and software provide these features.

Watch an earlier programme

01 Open a group or channel that supports **catch-up**. In the original Dutch layout, some groups include “Terugkijken” in their name.

02 Select the channel with **OK** and press **EPG** to open the programme guide.

03 Select a previously broadcast programme. Use **Left/Right** to move between programmes and, where available, the rewind/fast-forward buttons to change day.

04 Press **OK** and wait for the programme to load. Use **Play/Pause** to pause or resume playback.

How far back can you go?
The number of available days varies by provider and channel. The original guide mentions up to seven days for certain groups; this is not a guarantee for your source.

Turn on subtitles

01 Start the programme, film or episode.

02 Press the **yellow button**, select **Subtitles** and press **OK**.

03 Choose an available language and confirm with **OK**. Press **Back** to continue watching.

No subtitles or catch-up option?

Check another title or channel. If the source does not provide the feature, the box cannot add it automatically.

Locked categories

For a locked category, use the PIN set by you or your installer. If you have forgotten it, ask ASAT.NL about the controls on your particular model.

ASAT.NL does not supply streaming services or provide support for them.

From film nights to music.

The films, series and radio stations available are determined by your own content source.

Play a film

01 Press **VOD**. Select a group and press **Right**.

02 Select a film and press **OK** to open its details. Press **OK** again to play. In the original controls, the favourites option is one step to the right.

03 Use **Play/Pause** to pause and **Left/Right** to seek within the film. **Stop** ends playback; **Back** returns to the list.

Play a series

01 Press **Series**. Choose a group, move right and open the series with **OK**.

02 Select a **season**, if shown. Move right, choose an episode and press **OK**.

03 Use the same playback buttons as for a film. **Back** returns to episodes, series or groups.

Search by title

In the film or series list, move up to the **magnifying glass**. Press **OK** and enter part of the title. Select the result you want and press OK.

Listen to radio

Press **Radio**. Press **OK** for the station list, choose a station and confirm. Use **Live**, **VOD** or **Series** to switch to another section.

An empty list?
Check that your source has loaded and includes films, series or radio. The box itself does not supply channels or a subscription.

ASAT.NL does not supply streaming services or provide support for them.

06 · RECORDINGS

Save it to watch later.

Recording requires suitable storage and support from your model, software and content source.

Before you start
Insert a suitable USB drive or microSD card while the box is switched off. After switching on, check that the storage is recognised and has enough free space. Formatting deletes files: back them up first if formatting is needed.

Record immediately

01 Open the channel you want to record and press **REC**. Check for a recording symbol or remaining recording time.

02 Want to stop early? Press **Stop** and confirm with **OK**.

Schedule a recording

01 Choose the channel and press **EPG**. Select the programme you want to save.

02 Press **REC**, check the recording schedule on screen and press **Back** to return.

03 Keep the box, internet connection and storage available at the scheduled time. The controls described in the original guide require the box to remain switched on.

Play a recording

01 Press **Menu**, select **Recordings** and press **OK**.

02 Choose a recording and press **OK**. Use **Play/Pause** and **Left/Right** to control playback.

03 Press **Back** and confirm if prompted. Choose another recording or return to live TV.

The original manual describes one recording at a time and automatic switching to the channel being recorded. Your model may work differently. Try a short recording first. The storage folder named in the original is “MyTvLVideo”; using the Recordings menu is the easiest way to open it.

ASAT.NL does not supply streaming services or provide support for them.

Other useful features.

Play your own files, open YouTube or run through the first checks when something is not working.

Photos and videos from USB or microSD

01 Put photos and videos on the storage device, for example in folders named **Pictures** and **Movies**. Insert or remove the storage while the box is switched off.

02 From **Home**, open **Kodi** if it is installed on your box. Open the photo or video section, select the connected drive, then open a folder and file with **OK**. The original guide calls the drive “Disk”.

03 For photos, browse using **Left/Right**. For videos, use the on-screen playback controls. Press **Back** to leave playback.

The original guide lists BMP, JPEG, JPG and PNG for photos, and AVI, MP4, MKV and WMV for video. Actual playback also depends on the codec and app.

Open YouTube

Press **Home** and open **YouTube**, if available. Select the magnifying glass, enter a search term and open a result with OK. Use the on-screen playback controls; Back returns to the results.

No picture	Check the power supply, HDMI cable and selected HDMI input on your TV.
Buffering	Check your internet connection and try another channel. Use an Ethernet cable if possible.
Button not working	Check the batteries. For a Bluetooth remote, check pairing using the model’s manual.
No recording	Check storage, free space and whether the source allows recording.

Help with equipment
For purchasing, connecting and operating your Xsarius equipment:
WhatsApp or call **+31 475 407 278** · Open WhatsApp
ASAT.NL · xsariusbox.nl
For streaming services, channels, playlists and login details, contact your provider. ASAT.NL does not provide support for these.

ASAT.NL does not supply streaming services or provide support for them.